

·34

has to be adjusted to the Column (19). It is benefital to mount the drill motor to the stand for proper carriage/column weight distribution. Carriage Screw (25) can be tightened slightly to prevent the carriage and drill motor from traveling down the column prior to making any screw adjustments.

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.	FIG.
1	06-55-1525	1/4-20 Hex Nut	(5)	25
2	06-75-3050	1/4-20 x 3/4" Socket Hd. Screw	(4)	26
3	06-75-3920	5/16-18 Socket Hd. Screw	(3)	27
4	06-75-0970	1/2" Hex Hd. Cap Screw	(2)	28
5	06-75-5840	3/8-16 Socket Hd. Cap Screw	(4)	* 29
6	06-75-5845	5/8-11 Hex Hd. Cap Screw	(2)	* 30
* 7	06-83-5150	5/8-11 x 4-1/2" Hex Head Cap Screy		31
8	06-83-6010	1/4-20 x 1-1/2" Set Screw	(3)	32
9	06-83-6020	1/4-20 x 1" Set Screw	(3)	33
10	06-97-4110	5/16" Split Ring Lockwasher	(3)	34
11	06-97-4127	Lockwasher	(4)	35
13	06-97-4400	5/8" Split Ring Lockwasher	(2)	36
14	12-99-1310	Nameplate Blank	(1)	* 37
15	28-06-1110	Small Base	(1)	* 38
* 16	28-23-3415	Carriage	(1)	
17	36-66-4620	Pinion Shaft	(1)	
18	06-75-2950	1/4-20 x 1/2" Socket Hd. Cap Screw		
19	42-78-0050	Column	(1)	
22	43-96-0200	3/8 x 3/8 x 3" Key	(1)	
23	43-96-0210	3/8 x 3/8 x 5" Key	(1)	
24	43-98-0050	Plas)tic Knob	(2)	
		,	~ /	'

PART NO.	DESCRIPTION OF PART	NO. REQ.
43-98-0525	Carriage Screw	(1)
44-10-0365	Bar Handle	(1)
44-34-0190	Motor Mount	(1)
44-52-0605	Wear Pad	(1)
44-52-0665	Gib	(2)
44-52-0675	Wear Pad	(2)
44-80-0175	Rack	(1)
45-04-0535	Jack Screw Assembly	(1)
45-58-0280	Mounting Stud	(1)
45-88-7460	1/2" Flat Washer	(4)
45-88-8675	Shaft Washer	(1)
45-94-0135	Wheel	(2)
06-97-4050	1/4" Lockwasher	(4)
06-75-3090	1/4-20 x 7/8" Screw	(4)
49-96-0060	1/8" Hex Key	(1)
49-96-0080	3/16" Hex Key	(1)
49-96-0120	5/16" Hex Key	(1)

MILWAUKEE ELECTRIC TOOL CORPORATION

13135 W. LISBON RD., BROOKFIELD, WI 53005